How to view the Demo:

- Your Proteus is pre-configured to display a demo on a HD (1920 x 1080) video monitor.
- To view the demo, set up Proteus as shown in the diagram below
- Always ensure *microSD card is fully inserted* and *CFG switch (in rear panel) is in the UP position*
- Apply power to Proteus



How to disable Demo:

- Press *F9* to display menu. Go to *Config : Load* and press Enter. Select *Blank Screen* and press Enter.
- You can always restore the demo (or any other configuration) by going to *Config : Load* and selecting the desire file i.e. *ROV*

readme

Documentations:

1. Latest documentations can be download from our website: MicroSD FOLDERS – DOWNLOAD

 \sim

2. When you unzip the file, the content should appear as shown below:



- 3. Of course, your unit is shipped with a microSD that includes above folders.
- 4. To check firmware version, press Alt-H and a window should appear on your monitor.

The **User Manual** along with other documents reside in the *Documents folder*.

Quick Tutorial:

Disable the demo and follow the "Quick Tutorial" in the User Manual

Keyboard assigned functions

| Кеу | Description | | | |
|---|--|--|--|--|
| F1 | KML: Start recording | | | |
| F2 | KML: Stop recording | | | |
| F3 | KML: Drop place marker #1 | | | |
| F4 | KML: Drop place marker #2 | | | |
| F8 | Shortcut to "Edit: User Texts" | | | |
| F9 | Launch Main-Menu | | | |
| F10 | Save changes & exit Sub-Menu | | | |
| ESC | Abort changes and exit Sub-Menu | | | |
| Enter or Ctrl + Enter | Make a menu selection. Or select an item from the picklist i.e. COM1, COM2 | | | |
| Alt + G | Draw 60 x 60 pixel gridlines on video | | | |
| Alt + H | Help | | | |
| Alt + Ctrl + Shift + 2 | + Ctrl + Shift + 2 Layer 2: Display next page | | | |
| Alt + Ctrl + Shift + 3 Layer 3: Display next page | | | | |

When placing text, use the following Keys to format the text

| Кеу | | | Description | | |
|--------------|----|-----------------|---------------------|---|--|
| С | or | Ctrl + C | Color: | Change text foreground color | |
| F | or | Ctrl + F | Font: | Change font type | |
| W | or | Ctrl + W | Width: | Change width of the field | |
| J | or | Ctrl + J | Justify text: | Left, center or right justification text within field | |
| В | or | Ctrl + B | Background color: | Change text background color | |
| Ctrl + Arrow | or | Alt + Arrow | Move text location. | Hold Ctrl to move the field 20 pixels and Alt to move the field 2 pixels. | |